

TECH₂O

BESPOKE MIRROR TVs

Installation Instructions

In-Wall Installation Method

1. Create an opening within the chosen area of the wall. Please refer to your custom set of technical drawings for the specific recess dimensions that are relevant for your product.

2. Place the in-wall "wall hanger" bracket into the recess and use the pilot holes to drill into the wall. Place the raw plugs into the holes that have been drilled and fix the bracket into the required position.

3. Offer the television up to the bracket that is fixed within the wall. Line up the "mirror hanger" bracket (pre-assembled to television) with the "wall hanger" bracket within the wall and simply push the television into situ.

