



1. Drill four level holes within the wall and fix screws within the opening, leaving the screw heads proud. Please see the table below for fixing point distances that are relevant for your product. Please also ensure that the wall is able to hold the weight of the TV.
2. Carefully offer the television up to the screw heads that are fixed within the wall. Line up the side brackets (pre-assembled to television) with the protruding screws and simply hang the television onto the wall.



Installation Data					
Product	32"	42"	46"	55"	65"
Fixing Point Distances (W x H)	823 x 250mm	1041 x 250mm	1147 x 600mm	1338 x 707.5mm	1592 x 858mm

1. Attach the wall-mount section of the VESA bracket to the wall with the 4 x screws provided.
2. Attach the TV-mount section of the VESA bracket to the back of the television with the provided screws.
3. Simply offer the television up to the wall and slide the two brackets into one another, and then fix securely in place using the locking screws.



Installation Data					
Product	32"	42"	46"	55"	65"
Wall Bracket Compliance (W x H)	VESA 630 x 200mm	VESA 790 x 200mm	VESA 900 x 200mm	VESA 900 x 200mm	VESA 900 x 400mm