

The built in Sky Magic Eye IR Link System allows you to control Sky Digital broadcasts on your Television... Enabling you to view Sky television programmes and control the Sky box from another location.

To setup the Sky Magic Eye IR Link System, you will need to run a length of coax cable from the socket marked RF2 output on the back of the Sky box directly to the televisions aerial input. Sky television programmes can then be viewed on the ANALOGUE part of the tuner. Your Sky box needs to be set up to facilitate for an RF2 output. Please refer to your Sky user guide on how to do this.

Control of the Sky system is available via either a standard Sky remote control or the included learning remote control. The IR receiver within the television will receive the IR signal from the remote control, send it back down the aerial cable to the Sky box allowing you to have complete control from another location.

Please refer to the diagram below for illustrative reference of how to set up your Sky Magic Eye IR Link System:

